

2012-2017 Victory Cross Roads Hard-Ball Cross Country Magnum Service manual

# CROSS-ROADS/HARD-BALL/



## 2012 – 2017 Cross Roads, Hard-Ball, Cross Country, Magnum

Service Manual Chapter Summary

CHAPTER 1: GENERAL

**CHAPTER 2: MAINTENANCE** 

CHAPTER 3: FRAME / BODY / EXHAUST

CHAPTER 4: LUBRICATION / COOLING

CHAPTER 5: FUEL SYSTEM / FUEL INJECTION

CHAPTER 6: ENGINE REMOVAL / INSTALLATION

CHAPTER 7: CYLINDER HEAD / VALVES

CHAPTER 8: CYLINDER / PISTON

CHAPTER 9: CLUTCH, PRIMARY / SHIFT

CHAPTER 10: TRANSMISSION / CRANKSHAFT

**CHAPTER 11: DRIVE LINE** 

CHAPTER 12: FRONT WHEEL / SUSPENSION

**CHAPTER 13: REAR WHEEL / SUSPENSION** 

**CHAPTER 14: TIRES** 

**CHAPTER 15: BRAKES** 

CHAPTER 16: CHARGING SYSTEM

CHAPTER 17: IGNITION SYSTEM / BATTERY

**CHAPTER 18: ELECTRIC STARTER** 

CHAPTER 19: LIGHTING / INSTRUMENTATION

https://sellfy.com/workshopmanualdownload

## CHAPTER 1 GENERAL



GENERAL INFORMATION1.5
SERVICE RULES
VEHICLE INFORMATION
MODEL NUMBER DESIGNATION
VEHICLE IDENTIFICATION NUMBER (VIN) DESIGNATION
VIN NUMBER / MANUFACTURER LABEL
VECI / NECI / TIRE INFORMATION LABELS
ENGINE NUMBER LOCATION
KEY IDENTIFICATION NUMBER
SADDLEBAG WARNING LABEL
REAR SHOCK AIR PRESSURE LABEL
GENERAL SPECIFICATIONS
2012-2017 CROSS COUNTRY / CROSS COUNTRY TOUR / 8-BALL SPECIFICATIONS
2015–2017 VICTORY MAGNUM / MAGNUM X-1
VEHICLE LOADING1.13
GROSS VEHICLE WEIGHT RATING (GVWR)
PUBLICATIONS / TECHNICAL LITERATURE
PUBLICATION PART NUMBERS
REFINISHING1.15
PAINT COLORS BY MODEL1.15
PAINT COLOR CODES
BREAK IN PERIOD
BREAK-IN PROCEDURE
EMISSIONS
EMISSION CONTROL SYSTEMS1.20
EMISSION SOURCES
EXHAUST EMISSION CONTROL
NOISE EMISSION CONTROL SYSTEM
CRANKCASE EMISSION CONTROL
EVAPORATIVE EMISSION CONTROL
SPECIAL SERVICE TOOLS
GENERAL / PRECISION MEASURING TOOLS
TUNE UP & MAINTENANCE TOOLS
ELECTRICAL TOOLS
ENGINE, CLUTCH, & TRANSMISSION TOOLS
STEERING & SUSPENSION TOOLS
WHEEL & TIRE
FUEL SYSTEM & FUEL INJECTION
TOOL ORDERING INFORMATION
TRANSPORTING, ELEVATING, AND SECURING THE MOTORCYCLE
GENERAL GUIDELINES1.27
KEY SWITCH1.28

IGNITION KEY	1.28
IGNITION SWITCH	1.28
SPEEDOMETER / INSTRUMENTS - CROSS ROADS	. , 1.29
SPEEDOMETER	1.29
MULTI-FUNCTION DISPLAY (MFD)	1.29
SPEEDOMETER GEAR POSITION INDICATOR	1.29
INSTRUMENT CLUSTER	1.30
SPEEDOMETER / INSTRUMENTS - CROSS COUNTRY / MAGNUM	1.32
INSTRUMENT CLUSTER	1.32
MULTI FUNCTION DISPLAY (MFD)	1.33
ENGINE ERROR CODES	1.34
CLOCK	1.34
TRIP METER OPERATION	1.34
GEAR POSITION INDICATOR	1.34
ODOMETER	1.35
TEMPERATURE	1.35
CHANGING INFORMATION DISPLAY UNITS	1.35
CONSOLE SWITCHES (CROSS COUNTRY)	1.36
HAND GRIP HEATER SWITCH	1.36
SEAT HEATER SWITCH (CROS COUNTRY TOUR)	
LEFT HANDLEBAR SWITCHES. \{ \}	1.37
MODE BUTTON $\underline{\underline{8}}$	
HAZARD SWITCH (EMERGEN∰ FLASHERS)	1.37
HEADLAMP HIGH / LOW BEAM WITCH	1.37
TURN SIGNAL SWITCH 5	
TURN SIGNAL MOMENTARY FEATURE	
STARTER INTERLOCK	
RIGHT HANDLEBAR CONTROL	
ENGINE STOP SWITCH	1.39
ENGINE STARTER BUTTON	
FRONT BRAKE LEVER REACH DJUSTMENT (IF EQUIPPED)	
AUDIO / COM / CRUISE CONTROL BUTTONS	
AUDIO SYSTEM - CROSS COUNTRY TOUR	
RADIO / AUDIO SYSTEMS OP醛ATION	
SOFTWARE UPDATES	
RADIO FREQUENCIES	
AUDIO CONTROLS	
LOWER LEFT HAND CONTROL.	
UPPER LEFT HAND CONTROL*	
PASSENGER CB CONTROLS	
AUDIO SYSTEM POWER	
AUDIO VOLUME CONTROL	
AUDIO SOURCE SELECTION	
FM SOURCE ACTIVE	
AM SOURCE ACTIVE	
WX (WEATHER) SOURCE ACTIVE	
NAV MP3 SOURCE ACTIVE	1.42

	IPOD SOURCE ACTIVE	1.42
	AUX SOURCE ACTIVE	1.42
	SIRIUSXM RADIO SOURCE ACTIVE	1.42
	MW (MEDIUM WAVE) SOURCE	1.43
	LW (LONG WAVE) SOURCE	1.43
	AUDIO TUNING	1.43
	MEMORY PRESETS	1.43
	AUDIO MODE MENUS	1.43
	BASS SETTING MODE	1.44
	TREBLE SETTING MODE	1.44
	FADER SETTING MODE	1.44
	EXTERNAL SPEAKERS MODE	1.44
	AUTOMATIC VOLUME CONTROL (AVC) MODE	1.44
	CB HEADSET VOLUME CONTROLS MODE (IF EQUIPPED)	
	CB HEADSET ENT MODE (IF EQUIPPED)	
	DRIVER ICOM VOLUME MODE	
	DRIVER CB VOLUME MODE	
	CB LO/DX MODE	
	RADIO DATA SYSTEM (RDS) MODE	1.45
	AUX MODE	
	SIRIUSXM DISPLAY MODE*	
	SIRIUSXM CATEGORY ODE*	
	NOAA WEATHER BAND (WX)	
СВ	RADIO / ICOM SYSTE@	
	INTRODUCTION - CB RADIO FCC RULES	
	HEADSET USE	
	GETTING STARTED - C	
	CB CHANNELS	1.47
	PUSH-TO-TALK (PTT)	1.48
	SQUELCH. 2	1.48
	CB RADIO VOLUME SE TING (DRIVER)	
	CB RADIO VOLUME SETTING (PASSENGER)	
	CB LO/DX	
	CB FREQUENCIES	
	ICOM SYSTEM	
	VOX BREAK SETTING	
	ICOM VOLUME SETTING (DRIVER)	
	ICOM VOLUME SETTING (PASSENGER)	
	AUX / IPOD	
	INPUT CABLE SETUP	
	IPOD USE	
	IPOD PLAY LISTS	
Z R A	IPOD SONG CONTROL	
ΧIVI	RADIO	
	ABOUT SIRIUSXM RADIO.	
	GETTING STARTED - SIRIUSXM RADIO	
	SIRIUSXM RADIO RECEPTION	1.50

	SIRIUSXM RADIO MENU OPTIONS	1.53
	SIRIUSXM RADIO SETTINGS	
	SIRIUSXM CATEGORY SELECTION	1.54
	SIRIUSXM CHANNEL SELECTION	
	SIRIUSXM RADIO WIRING DIAGRAM	1.55
NΑ\	/ MP3	1.56
	BEFORE YOU BEGIN - NAV MP3	
	TIPS FOR NAV MP3 OPERATION	
	GETTING STARTED - NAV MP3	
AUE	DIO SYSTEM - CROSS COUNTRY 8-BALL	1.57
	AUDIO SYSTEM INTRODUCTION (8-BALL)	
	USING THE GLOBAL POSITIONING SYSTEM (GPS) INTERFACE	1.57
	AUDIO CONTROLS (8-BALL)	
AU	DIO SYSTEM - MAGNUM / MAGNUM X-1	1.58
	AUDIO SYSTEM INTRODUCTION	1.58
	IPOD / IPHONE DEVICE COMPATIBILITY	
	RADIO FREQUENCIES.	1.58
	RADIO SOURCES.	
	AUDIO MENU OPTIONS	
	AUDIO CONTROLS	1.59
	AUDIO DISPLAY	
	USB CONNECTOR	
	AUDIO DISPLAY ZONES	
	AUDIO SYSTEM POWER	
	AUDIO SYSTEM VOLUME	
	MUTE/PUSH-TO-TALK (PTT)	
	LOW VOLTAGE MUTE	
	SELECTING AUDIO SOURCES	
	VOICE RECOGNITION MODE	
	SIRI EYES FREE	
	AUDIO MODE MENUS	
	AUDIO SYSTEM DIAGNOSTICS	
	AUDIO COMPLIANCE INFORMATION	
REF	FERENCE	
	SAE TAP / DRILL SIZES	
	METRIC TAP / DRILL SIZES	
	DECIMAL EQUIVALENTS	
	CONVERSION TABLE	
	FAHRENHEIT TO CELSIUS	1.77

#### **GENERAL INFORMATION**

#### **SERVICE RULES**

In order to perform service work efficiently and prevent costly errors, technicians should read the text in this manual and familiarize themselves with the procedures before beginning. Notes, Cautions and Warnings have been included for clarification of text and safety concerns. Knowledge of mechanical theory, tool use and shop procedures are necessary to perform some procedures in this manual safely and correctly.

Use only genuine Victory service parts, including fasteners that require replacement if removed. Do NOT substitute fasteners or hardware.

Cleanliness of parts and tools as well as the work area is of primary importance. Dirt and foreign matter will cause damage to precision parts. Clean the motorcycle before beginning service. Clean all parts before installing.

If difficulty is encountered in removing or installing a component, look to see if a cause for the difficulty can be found. If it is necessary to tap the part into place, use a soft face hammer and tap lightly.

Always follow torque specifications as outlined throughout this manual. Incorrect torquing may lead to serious machine damage or in the case of steering, driveline, and chassis components, can result in loss of control during operation of the motorcycle, which may result in severe personal injury or death.

If a torquing sequence is indicated for nuts, bolts or screws of a certain component, start all fasteners and hand tighten. Following the method and sequence indicated, tighten evenly to the specified torque value. When removing nuts, bolts or screws from a component with several fasteners, loosen them all about 1/4 turn before removing them to prevent distortion of that component.

Replace all oil seals, sealing washers, gaskets, and O-rings with new ones during assembly. Be sure the mating surfaces for the gasket are clean and smooth to avoid leaks and maintain specified tolerances.

Some procedures require removal of retaining rings or clips. Removal can weaken and deform these parts, therefore, they should always be replaced with new parts. When installing new retaining rings and clips, use care not to expand or compress them beyond what is required for installation.

Victory lubricants and greases have been specially formulated to provide maximum performance and protection when applied properly. In some applications, warranty coverage may be void if improper lubricants are used.

Parts requiring grease should be cleaned thoroughly and fresh grease applied before reassembly. Deteriorating grease loses lubricity and may contain abrasive foreign matter. Always replace locking hardware such as lock nuts or lock washers, fasteners that have pre-applied locking agent, or any other fasteners as noted in this service manual with genuine Victory hardware from an authorized Victory dealer. Working with batteries can be hazardous. Review all battery warnings and cautions.

#### VEHICLE INFORMATION

#### MODEL NUMBER DESIGNATION

Example: V16DW36NA

GROUP	MODEL	MODEL	MODEL TYPE	ENGINE SIZE	ENGINE HP	SERIES	COLOR	PREMIUM DESIGNA- TION
1st	2/3rd	4th*	5th*	6th*	7th*	8th	9th**	10th
V	14 15 16 17	B = Cross Roads C = Cross Country LE D = Cross Country G = Vegas H = Hammer L = Gunner M = Judge R = Boardwalk S = Vision Tour T = Cross Country Tour U = Magnum X-1 W = High- Ball X = Jackpot Y = Magnum Z = Ness Magnum	A = 8 Ball B = Standard R = Sport (Forward) S = Sport (Mid) W = ABS	1 = 1507 cc (92 ci) 2 = 1634 cc (100 ci) 3 = 1731 cc (106 ci)	6 = Free- dom 106	E = Int'l N = North America	A = Black B = Gloss Black C = Pearl White D = Sunset Red E = Titanium Crystal H = Havasu Red J = Blue Fire L = Matte Titanium / Flames M = Black Crystal / Antifreeze Grn N = Black Crystal / Havasu Orange Pearl P = Matte Pearl White R = Black Pearl / Sunset Red T = Matte Titanium U = Turbo Silver V = Black Crystal / Ness Graphics W = Gloss Pearl White X = Suede Sagebrush Green Y = Matte Pearl White Z = Sunset Red	C = California A = Canada

<sup>\* =</sup> digits that would transfer to 17 digit VIN and are used in digits 4-8 respectively.

\*\* = 9th digit will be used on color/featured versions of models (not including the base).

First 3 digits and 9th digit are used in model number only. They are not used with the 17 digit VIN.

### 1

#### VEHICLE IDENTIFICATION NUMBER (VIN) DESIGNATION

Example: 5VPXB36N0C3000000

The Company of the C		VEHICLE DESCRIPTORS					VEHICLE IDENTIFIERS									
	WORLD MFG. ID		CHASSIS	TYPE	ENGINE	ENGINE HP	SERIES	CHECK	MODEL YEAR*	MFG. LOCATION				NUM.		
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
5	V	Р	Х	В	3	6	N	0	С	3	0	0	0	0	0	0


#### VIN NUMBER / MANUFACTURER LABEL

The Manufacturer Information Label ① contains the following:

- · Vehicle Identification Number
- · Gross Vehicle Weight Rating.
- Gross Axle Weight Rating.
- Tire and Wheel Information.
- · Date of Manufacture.


#### **VECI / NECI / TIRE INFORMATION LABELS**

The Vehicle Emission Control Information (VECI) and Noise Emission Control Information (NECI) ② label is located on the left side of the head tube.



#### **ENGINE NUMBER LOCATION**


The engine number ③ is stamped into the right crankcase boss and identifies engine model and serial number.



#### **KEY IDENTIFICATION NUMBER**

The key identification number is stamped on a tag attached to the key ring. If key and identification number are lost or misplaced, the lock set must be replaced.

Key blanks are available from Victory. Locksmiths familiar with the motorcycle industry will be able to cut a replacement key with an I.D. number and a key blank.




#### SADDLEBAG WARNING LABEL

Saddlebag Warning Label 5.

#### REAR SHOCK AIR PRESSURE LABEL

Rear Shock Air Pressure Label 6.



#### **GENERAL SPECIFICATIONS**

#### 2012-2017 CROSS COUNTRY / CROSS COUNTRY TOUR / 8-BALL SPECIFICATIONS

		CROSS COUNTRY / 8-BALL	CROSS COUNTRY TOUR						
DIMENSIONS	Oil Capacity	5.0 Qt. (4.75 ltr) (Approximately 4.5 qts. or 4.25 L at oil & filter change)							
	Fuel Capacity	5.8 US Gal (22.0 L) (1.0 U.S. gal / 3.8 L reserve)							
	Fuel Type / Octane Minimum	Premium Unlead	ded / 91 Octane						
SNS	Dry Weight	768 lbs (348 kg) / 746 lbs (348 kg)	844 lbs (383 kg) / 760 lbs (345 kg)						
ME	Wet Weight	800 lbs (363 kg) / 781 lbs (354 kg)	876 lbs (398 kg) / 795 lbs (361 kg)						
CAPACITIES & D	Gross Vehicle Weight Rating	1360 lbs (618 kg)							
	Gross Axle Weight Rating	Refer to Manufacturer Information label on frame of vehicle (left side of steering hea							
	Maximum Load	Subtract Wet Weight from GVWR or refer	to Rider's Manual. Never exceed GVWR						
ડે	Overall Length	104.3 in. (265.0 cm) / 104.3 in. (265.0 cm)	108.1 in. (274.7 cm) / 104.3 in. (265.0 cm)						
	Overall Width	39.3 in. (9	99.9 cm)						
	Overall Height	52.5 in (133.3 cm)	60.0 in. (152.5 cm) / 53.2 in. (135.1 cm)						
	Seat Height	26.25 in (	66.7 cm)						
	Ground Clearance	5.8 in (1	4.8 cm)						
	Total Storage Volume	21.3 gallons (80.6 L) / 21.3 gallons (80.6 L)	38.7gallons (146.5 L) / 21.3 gallons (80.6 L)						
	Passenger Capacity	1							
	Wheelbase	65.7 in (1	66.9 cm)						
	Rake / Trail	29 Degrees / 5.	6 in. (14.2 cm)						
	Engine Type	VICTORY Freedom® V-Twin							
	Engine Configuration	50° SOHC V-	Twin 4 Stroke						
	Engine Displacement	1731cc / 106 cubic inch 6 speed (106 / 6 engine)							
	Engine Cooling System	Air /	Oil						
	Compression Ratio	9.4	<del>:</del> :1						
	Compression Pressure	210 - 225 psi (14	148 - 1551 kPa)						
INE	Valve Train	4 Valves per cylinder. Hydraulic Lifters &	Cam Chain Adjusters (No Adjustment)						
ENGINE	Bore x Stroke	101 x 1	08 mm						
ш	Idle Speed / Fast Idle Speed	NOT ADJUSTABLE - ECM Controlled by I	AC (Spec Idle Speed is 950 +/- 100 RPM)						
	Fuel System / Throttle Body Bore Size	Closed Loop Sequential Electronic	Fuel Injection / Dual Bore 45 mm						
	Exhaust System Type	Split Dual Exhaus	t With Crossover						
	Lubrication System	Wet S	Sump						
	Spark Plug Type (Gap)	NGK DCPR6E (.	.032 in. / .8 mm)						
S	Dry Weight (Engine Approximate)	265 lbs (120 Kg)							
KE	Brake Type (Front / Rear)	Disc /	Disc						
BRA	Front Brake	Dual 300x5mm Floating Di	sc / 4 Piston Calipers ABS						
_	Rear Brake	Single 300x7mm Floating D	Disc / 2 Piston Caliper ABS						



		CROSS COUNTRY / 8-BALL CROSS COUNTRY TOUR			
	Transmission Type	Manual, 6 Speed Constant Meshwith True Overdrive			
Σ	Primary Reduction Ratio	1.49:1			
DRIVESYSTEM	Final Drive / Ratio / Belt Width	Carbon Fiber Reinforced Belt / 2.12:1 / 28mm			
VES	Gear Shift Pattern	1 Down, 5 Up			
ORI	Internal Gear Ratios 1st	3.13:1			
	2nd	2.02:1			
	3rd	1.50:1			
	4th	1.20:1			
	5th	1:1			
	6th	0.87:1			
	Front Wheel (Size / Type)	Cast or Billet / 3.5 x 18 (inch) Spoke Type — 3.50 X 18"			
	Rear Wheel (Size / Type)	Cast or Billet 5.00 x 16 (inch) Spoke Type — 5.00 X 16"			
z	Front Tire	Dunlop D418F Elite 3- 130/70 R18 63H Radial Dunlop 491 Elite II — 130/70–18 63H Bias-PLy (Tube Type)			
SUSPENSION	Rear Tire	Dunlop D418 Elite 3 - 180/60R16 M/C 80H Radial Dunlop D418 Elite 3 — 180/60R16 M/C 80H Radial (Tube Type)			
JSP	Minimum Tread Depth	.063 in. (1.6mm)			
ร	Front Type	Inverted Telescopic Cartridge Fork			
	Front Travel	, 5.1 in. (13 cm)			
	Front Tube Diameter	43 mm (1.7 in.)			
	Rear Shock Type	Single, Monotube Air Adjustable Shock			
	Rear Swingarm Type	Cast Aluminum with Constant Rate Linkage			
	Rear Travel (inches)	4.7 in (12 cm)			
	HID Headlamp	High H-11 / Low: D1SR			
TS	Turn Signal Lamp	Non-Serviceable LED			
LIGHTS	Brake / Tail / License Plate Lamp	Non-Serviceable LED			
	Alternator / Battery	625W (48A @ 13.0VDC) / 12V 18AH 310 CCA			
	Turn Signal / Horn	10 amp fuse			
	Chassis	20 amp fuse			
S	Engine	15 amp fuse			
FUSES	Fuel Pump / Ignition Coil	15 amp fuse			
Ħ	Ignition	10 amp fuse			
	Lights	20 amp fuse			
		See fuse box label Fuse Replacement (Main Fuse Box), page 2.38			
	Circuit Breakers				
	Fuel Type	Premium Unleaded / 91 Octane Minimum  3.51 BAR (351 kPa) (51 psi)			
	Fuel Pump Pressure				
FUEL	Fuel Pump Volume	60 liters / hr (500 ml or 16.9 oz. / 30 seconds) (0.26 gal / min) (@ 12 V)			
F	Resistance	Empty: 250 Ohms / Full: 50 Ohms			
	Fuel Pump Current Draw	Less than 5.0 Amps			
L	Fuel Injector Resistance	11.4 - 12.6 Ohms			

Specifications may change with the addition of custom order options and / or accessories. Polaris Industries Inc. reserves the right without prior notice to discontinue at any time at its discretion any of the items herein or change specifications or designs without incurring any obligation to the customer.

### 1

#### 2015-2017 VICTORY MAGNUM / MAGNUM X-1

Sin.		MAGNUM / NESS	MAGNUM-X1					
	Oil Capacity	5.0 Qt. (4.75 ltr) (Approximately 4.5	oqts. or 4.25 L at oil & filter change)					
	Fuel Capacity	5.8 US Gal (22.0 L) (1.2	U.S. gal / 4.51 L reserve)					
ENSIONS	Fuel Type / Octane Minimum	Premium Unlea	ded / 91 Octane					
NS	Dry Weight	778 lbs (353 kg)	787 lbs (357 kg)					
DIME	Wet Weight	810 lbs (367 kg)	822 lbs (373 kg)					
ES & C	Gross Vehicle Weight Rating	1310 lbs.	(595 kg)					
E	Gross Axle Weight Rating	Front Axle: 460 lbs. (209 kg)Rear Axle: 850 lbs. (386 kg)						
CAPACIT	Maximum Load	491 lbs. (223 kg)	497 lbs (225 kg)					
ે	Overall Length	104.6 in. (	265.7 cm)					
	Overall Width	39.3 in.	(100 cm)					
	Overall Height	53.8 in. ( <sup>-</sup>	136.7 cm)					
	Seat Height	25.7 in (	65.4 cm)					
	Ground Clearance	5.3 in (1	3.4 cm)					
	Total Storage Volume	21.3 gallons	s (80.6 liters)					
	Passenger Capacity	1						
	Wheelbase	65.7 in (167 cm)						
	Rake / Trail	29 Degrees / 5.6 in. (14.2 cm)						
	Engine Type	VICTORY Freedom 106 / 6 V-Twin						
	Engine Configuration	50 SOHC V-	Twin 4 Stroke					
	Engine Displacement	1731cc / 106 cubic inch 6 speed (106 / 6 engine)						
	Engine Cooling System	Air / Oil						
	Compression Ratio	9.4:1						
	Compression Pressure	210 - 225 psi (1448 - 1551 kPa)						
H	Valve Train	4 Valves per cylinder. Hydraulic Lifters & Cam Chain Adjusters (No Adjustment)						
ENGINE	Bore x Stroke		108 mm					
"	Idle Speed / Fast Idle Speed	NOT ADJUSTABLE - ECM Controlled by	IAC (Spec Idle Speed is 950 +/- 100 RPM)					
	Fuel System / Throttle Body Bore Size	•	c Fuel Injection / Dual Bore 45 mm					
	Exhaust System Type		st With Crossover					
	Lubrication System		Sump					
	Spark Plug Type (Gap)	NGK DCPR6E	(.032 in. / .8 mm)					
,,	Dry Weight (Engine Approximate)	265 lbs	(120 Kg)					
X T	Brake Type	Disc	/ Disc					
BRAKE	Front Brake	Dual 300x5mm Floating D	isc / 4 Piston Calipers ABS					
"	Rear Brake	Single 300x7mm Floating	Disc / 2 Piston Caliper ABS					

## **Download Link**

https://sellfy.com/p/oytz/